

Set of two high quality clay fired pizza stones and a wide bodied pizza paddle. Suitable for BBQs and Electrolux 90cm and 60cm ovens. Can be used both indoors and outdoors.



Product Details

FEATURES

Designed to suit the
Electrolux ProLine™
Barbecue

Pizza Stones

Wide-Bodied Pizza Paddle

BENEFITS

Designed to suit the Electrolux ProLine™ Barbecue

Pizza Stones

The Electrolux Pizza Stones are designed to create quality pizza crusts each and every time. Having two stones, means you can use both stones at the same time in a 90cm oven. Or use one stone outdoors in the BBQ and the other indoors in your Electrolux 60cm oven.

Wide-Bodied Pizza Paddle

The Electrolux Pizza Pack contains a wide-bodied wooden paddle so you can easily add and remove your pizza from the hot stone. Unlike traditional spatulas, which are short and narrow, this well-designed paddle can safely lift the pizza off the pizza stone without losing any of the precious topping.

A five-star barbecue experience

From a Gourmet Pizza Pack to protective weatherproof covers, our broad range of optional extras can help you create your perfect barbecue. Plus, whether you prefer an open grill or a solid hotplate, our range of customisable cast iron furnishings offers different cooking configurations to suit your needs.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs) 1

Product Relates to Oven

SPECIFICATIONS

Material Ceramic / Refactory

SHIPPING

Shipping Volume (m3) 0.0129165

Shipping Weight (Kg) 7.21

Pack Dimensions Height (mm) 545

Pack Dimension Width (mm) 395

FEATURES

Accessory Other Features Hypo allergenic,Easy grip

DIMENSIONS

Total height (mm) 380

Total width (mm) 327

Total depth (mm) 14

SHIPPING

Pack Dimension Depth 60
(mm)

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz