

BBQ Tongs



Product Details

FEATURES

Secure grip for control and precision	Sturdy construction from stainless steel with heavy duty handle	Multi-purpose for a range of barbecuing jobs	Dishwasher safe for ease of maintenance
Hang with ease convenient hanging hole			

BENEFITS

Secure Grip Our BBQ tongs offer a firm and secure grip on various foods, allowing you to effortlessly flip, turn, and manoeuvre them on the grill. The spring-loaded design with locking mechanism ensures optimal control and precision.	Durable Construction Made with durable stainless steel and heat-resistant plastic, our BBQ tongs can withstand high temperatures, providing a reliable tool for handling hot food safely.
Multi-Purpose Our BBQ tongs are a versatile tool suitable for a wide range of barbecuing tasks. From flipping burgers to handling delicate vegetables or even rearranging charcoal, these tongs are designed to handle various foods and barbecuing techniques with ease.	Dishwasher Safe Our BBQ tools are hassle-free when it comes to clean up. Simply toss them in the dishwasher, and they'll come out spotless, ready for your next barbecuing session. Enjoy the convenience and ease of maintenance with our dishwasher-safe BBQ tools.
Hang with Ease Our BBQ tools feature a convenient hanging hole, making storage a breeze. Keep your grilling essentials within reach and neatly organised by easily hanging them on hooks or racks. With the built-in hanging hole, your BBQ tools are always ready for action, saving you time and ensuring a clutter-free barbecuing experience.	



Specifications

PRODUCT PROFILE

Product Relates to	BBQ
--------------------	-----

DIMENSIONS

Total height (mm)	430
Total width (mm)	40
Total depth (mm)	45

FEATURES

Accessory Other Features	Quick & easy installation,Stainless steel,Dishwasher cleanable,Non-stick surface,Durable construction,Easy to clean,Universal
--------------------------	---

SHIPPING

Shipping Volume (m3)	0.038
Shipping Weight (Kg)	0.4
Pack Dimensions Height (mm)	478
Pack Dimension Width (mm)	106
Pack Dimension Depth (mm)	51

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz